

Maintenance Kit

Part No.: HHPK



The Ingram HHPK is a replacement part for the HH20P Air compressor

Features / Technical Specifications

- Repair kit for HH20P air compressor
- Use Silicon/Teflon lubrication oil for piston-cylinder
- Use #20 Non-Detergent oil on bearings

Directions

Remove Phillips head screw on piston-cylinder.
Loosen piston screw on shafts. Replace with HHPK

